



ASSEMBLY OF THE UMS MOUNT ON THE IB(E) PRODUCTS



screwdriver

IB/E adapter

UMS mount

remove the 4 slotted-head screws from
The PL-Mount extension
with the delivered slot screwdriver
(don't unscrew any other screws!!!)

Take good care of those screws –
you need will them again
when you assemble the
standard version again!!!



slotted-head screws

PL Mount extension

Removing of the PL-Mount extension- result

22.05.2024

now you have these two parts



Adapter without PL extension



PL extension with screws


IB(E Adapter

Mounting the UMS mount (for example the UMS EF)

22.05.2024

1.) Slip the UMS mount on the adapter.
Be aware that you do that without tilting it so
You do not cant it.

2.) When you look at the PL mount you can see the
position recess. The UMS has one screw PL-mount sided.
These two parts have to be fit together and thats it.



Rotation (counterclockwise)



lock ring of the UMS Mount



To fix the UMS mount on the adapter you just have to turn the lock ring Tightly counterclockwise



Now your adapter with UMS mount assembled and ready to go!